

## How to open your Xbox 360 easily without marking it

By Hippo | On May 25, 2006 | In [Front Page News](#) | Rated ★★★★★

# How to open your Xbox 360 easily without marking it

XBox 360's are expensive and I like to keep things unmarked/scuffed when I open them up, here's how!

## How to open your Xbox 360 easily without marking it

XBox 360's are expensive and I like to keep things unmarked/scuffed when I open them up, here's how!

Note, you can use screwdrivers to open the xbox 360 case, but when you do it will scuff the plastic leaving at the console has been opened, this way will leave you with an unmarked xbox 360. there are guides for the basic disassembly all over the net including here <http://www.informit.com/articles/article.a...430626&seqNum=2>

### Step 1


If you're opening up a 360 you're probably going to backup some games. so take the tub your spindle of discs came in (i used a 50 dvd-r tub by traxdata myself) and cut a bit from the side of it and put it over the console as shown. then mark out where the holes are...



... then make it into a key like this. the tabs need to be about 1cm long.



then do the same for the other side and you'll get two xbox 360 case opening keys that look like these...



## Step 2

open the front of the console as normal and put a bit of newspaper or something inside the case to hold the front open a bit, then insert the key, push with a bit of force and

you should hear it click and the case will open....



... repeat for the other side and you're done!

There, one open unmarked xbox 360!



Thanks Hydra for this simple solution from parts we all have around the house.

